


ASSEMBLY HARDWARE



- A. Custom print
- B. Stakes
- C. Black polyester Inflatable core arch
- D. Carrying case



ASSEMBLY



(We recommend at least 3 people to assembly the arches)

1. Lay the inflatable core arch out flat.
2. Find the valve, there are two, one on each base of the arch, and make sure they are secure. Once they are secure, open the top piece of the valve on one side.
3. The easiest way to fill the arch is with an electric pump. Begin to fill the arch till it is about halfway filled. (This makes it easy to put the prints on.)
4. Take the custom print and carefully put part of it under the arch.
5. Start on one end of the print and work the hook-and-loop fastener together. Make sure the hook-and-loop fastener goes along the zipper of the arch.
6. Repeat this process for the other prints. Once the prints are securely on the arch, finish filling the inflatable core.
7. With one person on one side and another on the other side of the arch, carefully lift the arch to stand tall.
8. While two people hold the arch up, someone else can attach the stake to the rope and make sure it is taut.
9. Gently hammer the stake into the ground. Once all the stakes are in the ground the arch will stand by itself.
10. Your inflatable arch is ready to use.