



ASSEMBLY HARDWARE



ASSEMBLY FOR SINGLE BANNER STAND



1. Fold out stabilizing foot on the banner stand until it locks into place.
2. Set the banner stand on the ground upright.
3. Assemble the support pole by connecting the segmented pole sections.
4. Slide the support pole through the hole on the back of the base and place it into the slot at the bottom of the base.
5. With clean footwear, step on the folded-out foot and pull the up until it meets the clamping rail. Connect the clamping rail to the support pole by sliding the lip of the rail (in the center) over the end of the support pole.
6. Your retractable banner stand is now assembled.

ANGLE LINK & TRIPLE BANNER ASSEMBLY



1. Angle link can attach to retractable banner stand either open or closed.

2. Click the angle link to the bottom of the base.

3. If angle link is closed when attached to the first banner stand, open it up to connect the second banner stand.

4. Line up the bottom of the second banner stand and gently push down to connect it to the other side of the link.

5. Repeat this process to add the third banner stand.

6. Once all three banner stands are connected, move them into a triangle shape.

7. Then, attach the 3rd angle link to ensure all banner stands are connected.

8. The triple banner display is now ready to use!