


X-Display Plus & X-Display Economy

R2.033114




- 3 Aluminium rods joined by a connector
- 2 Fiberglass reinforced plastic rods
- Carrying Case

1




1. Fit the plastic rods into the sleeves of the plastic connector

2




2. Press the button in the center of the connector to unfold the rods to the width of the display

3



3. Fix the grommets on the corners of the image to the hooks at the Fiberglass rod ends

4



4. Stand the display up, folding back the center Aluminium rod to a position that suits best

X-DISPLAY PLUS



- 5 Fiberglass reinforced plastic rods joined by a plastic connector
- Economy Bag

1




1. Unfold the fiberglass reinforced plastic rods

2



2. Fix the grommets on the corners of the image to the hooks at the Fiberglass rod ends

3



3. Stand the display up, folding back the center Aluminium rod to a position that suits best

X-DISPLAY ECONOMY